

USING DECALS: A SIMPLE STEP-BY-STEP GUIDE

TO APPLY YOUR DECALS YOU WILL NEED THE FOLLOWING TOOLS:

- SCISSORS
- A KITCHEN TOWEL
- A BOWL OF WARM WATER
- A SQUEEGEE OR MUDTOOL
- A SOFT LINT-FREE CLOTH
- A CERAMIC/ GLASS/ ENAMEL BODY
- A KILN

STEP 1. PREPARE YOUR WORK SPACE BY LAYING YOUR KITCHEN TOWEL FLAT ON A TABLE WITH THE SCISSORS, WATER, SQUEEGEE AND CLOTH. WASH YOUR CERAMIC/ GLASS/ ENAMEL BODY IN WARM WATER.



STEP 2. REMOVE THE WAX PAPER FROM YOUR DECAL IF PRESENT AND CAREFULLY CUT AROUND YOUR DECAL.



STEP 3. PLACE THE DECAL IN THE WARM WATER AND WAIT AT LEAST 30 SECONDS. REMOVE THE DECAL AND LET IT SIT UNTIL THE DECAL SLIDES EASILY FROM THE BACKING PAPER WITH LITTLE PRESSURE.

STEP 4. SLIDE THE DECAL OFF THE BACKING PAPER ONTO YOUR CERAMIC/ GLASS/ ENAMEL BODY. DO NOT FLIP THE DECAL OVER. IT IS VERY IMPORTANT THAT THE DECAL REMAIN FACE-UP.



STEP 5. CAREFULLY HOLD YOUR DECAL IN PLACE WHILE YOU USE YOUR SQUEEGEE TO PUSH OUT ANY WATER OR AIR BUBBLES TRAPPED UNDER THE DECAL. START FROM THE CENTER OF THE DECAL AND PUSH OUT TOWARD THE EDGE, ROTATING YOUR CERAMIC/ GLASS/ ENAMEL AS YOU CAREFULLY REMOVE ALL AIR AND WATER FROM UNDER THE DECAL.

STEP 6. CAREFULLY DRY YOUR DECORATED CERAMIC/ GLASS, ENAMEL BODY, WITH A SOFT, LINT-FREE CLOTH (E.G. OLD PILLOWCASE) WORKING FROM THE CENTER OF THE DECAL, GENTLY PUSHING TOWARDS THE EDGE OF THE DECAL. ALLOW DECAL TO DRY OVERNIGHT AND FIRE AS PER THE FIRING INSTRUCTIONS INCLUDED WITH YOUR DECALS.



Using Milestone Decals on Glass

Milestone decals are printed on paper that is coated with a water-release adhesive made of dextrin. A layer of wax paper protects the decal.

Applying

1. Remove the layer of wax paper.
2. Thoroughly wet the decal in a bowl of warm water until it uncurls. This usually takes about 30 seconds, depending on the temperature of the water and the size of the decal. Do not let the decal sit in the water for more than a minute or two.
TIP: Be sure to remove your decal from the water before it floats off the backing paper – otherwise you might accidentally apply it upside down and it will not adhere properly.
3. Place the wet decal still on the backing paper on top of your glass and let it sit for 2-3 min. This allows for the glue under the decals to soften. The decals should release from the backing paper easily with no resistance. If the decal is not releasing easily, quickly re-wet and allow the decal to rest for a short while longer on your glass while the glue softens. Larger decals may need to rest longer in water.
4. Gently slide the decal from the backing paper at the desired position onto the clean glass. **The decal should sit glue side down on the glass** (think sticker not temporary tattoo). Using first a small squeegee (or rubber/silicone spatula) and then a lint-free cloth, gently press and push out the water from the center of the decal toward the edge following a clockwise motion. Repeat the process with increased pressure. Ideally, you will squeeze all water and any air bubbles from underneath the decal.
5. Once applied, you shouldn't be able to move the decal. Clean the surface with a damp, lint-free towel to remove any watermarks and then a dry, lint-free towel to wipe it clean. If possible, let the decorated ware sit in a dry environment overnight (or at least a couple of hours) before firing.

Safety

The decals should be fired in a well-ventilated room, preferably one that ventilates to the outside.

Firing

- Make sure the kiln is well-ventilated up to 1000°F(540°C)
- The decals should be fired very slowly below 500°F (260°C)
- The non metallic decals are somewhat translucent. To help keep their density, it is best to:
 - use them on white or light colors
 - fuse them to glass at the lower temperature allowed by your process.
 - soak them longer at lower temperature if possible when slumping or capping the decal with glass.

Uncapped Decal (decal not covered with glass):

Rate	Temperature	Hold
80°F (30°C)	185°F (85°C)	:20 min.
185°F (85°C)	400°F (200°C)	:15 min.
250°F (120°C)	700°F (370°C)	:15 min.
1000°F (540°C)	1240°F (670°C) to 1300°F (700°C)	:10 min.

Anneal according to the needs of the piece.

Capped Decal (decals sandwiched in glass):

Rate	Temperature	Hold
80°F (30°C)	185°F (85°C)	:20 min.
185°F (85°C)	400°F (200°C)	:15 min.
250°F (120°C)	700°F (370°C)	:15 min.
1000°F (540°C)	1370°F (740°C) to 1470°F (800°C)	:0.5 hr. to 3 hr.

Anneal according to the needs of the piece.

Etch Decals:

Rate	Temperature	Hold
80°F (30°C)	185°F (85°C)	:20 min.
185°F (85°C)	400°F (200°C)	:15 min.
250°F (120°C)	700°F (370°C)	:15 min.
1000°F (540°C)	1150°F (620°C) to 1200°F (650°C)	:10 min.

Anneal according to the needs of the piece.

Using Milestone Decals on Glass

The most common issues decal users have result from either applying the decal upside down or from not removing all of the water and air from under the decal. Take care to read the instructions thoroughly before applying your decals.

FAQs :

1. Why are the decals tinted yellow/orange/green?

We use a tint in the covercoat or flux to help ensure proper coverage of the decals. Don't fret! The tint is in the finish coating and will NOT be visible after the decal has fired.

2. Why do my metallic gold, silver or copper decals look dull and brown?

The metallic colors need to be fired to show their luster shine. Be careful not to mix up your metallic colors as they look very similar to one another.

3. My white decals look pink and smeared?

Printing white on white paper is tough! In order to ensure that the print is good and that the decals can be cut safely, we use a pink dye in our white ink. This dye will burn away during the firing. The pink dye has a tendency to migrate in the covercoat around the decals which result in a decal that looks smudged and blurry. This will not affect the quality of the fired decal.

4. There is nothing left on the ware after firing or sometimes a small puddle of color?

The decals were applied upside down. The decal sits on the paper on the same side that they should sit on the ware. If the decals floats off the backing paper in the water, it is easy to lose track of what the right side is. If you aren't sure if your decal is upside down or not, visit the item on our website to see the correct orientation.

5. After firing, the decals have pinholes and blowouts. What happened?

These holes come from water or air bubbles that have remained underneath the decal. With your next decal application, use warmer water and also slightly warm up the ware. You can soak the ware in a tub of hot water. The ware should be not hotter than body temperature. Also, try to ensure that you use a rubber/ silicone tool to chase all the air and water out and then wipe clean and dry with a lint free cloth. You also may want to consider letting the decal air dry for several hours. A close inspection under a light after the drying period should reveal any air bubbles. Using a thin needle, pierce the bubbles and use a piece of paper towel moistened with hot water to reapply the area. If your ware or clay is very textured or undulating then it will likely be difficult to avoid pinholes and blow outs.

6. Where can I find a small squeegee?

Some of our clients speak well of Flexible Rib squeegees made by Mudtools. We'd recommend the medium or firm flex. A kitchen spatula will also work in a pinch.

7. The decal wiped right off after firing? What happened?

This can sometimes happen if you neglect to remove the white paper backing or wax paper on top before applying and firing. This can also happen if you accidentally apply the decal upside down or underfire it. Decals that are underfired will have the glass pigment powder unbonded to the ware and would wipe off. It is still possible to return it to the kiln at a higher temp to get to the fusing temperature.

All text, graphics, photographs and the selection and arrangement thereof are Copyright of Milestone Decal Art LLC. ALL RIGHTS RESERVED. Any use of materials in this document, including reproduction, modification, distribution or republication, without the prior written consent of Milestone Decal Art LLC, is strictly prohibited. If you have purchased our decals we hereby grant you permission to sell your finished wares commercially using our decals.